

Classroom Camera Control Guide

Use the **“Light”** icon to turn on/off the camera light.

Use the **“Power”** icon to turn on the camera. *There’s no need to ever turn it off.*

The **LED** turns blue when camera is on and red when it is off.

The **Microphone** is located in this area and is hidden. It is readily available for use.


Push the **“Auto Focus (AF)”** icon to focus the camera. One push and it’s done.

Use the **“Brightness”** and **“Darken”** icon to brighten or darken an image.

Use the **“Rotate”** icon to rotate an image 0°/180°. *Tip: For a 90° adjustment rotate the camera head.*

Push the **“Freeze”** icon to pause/restart an image. *Tip: The center LED will flash yellow when “Freeze” is enabled.*

Use the **“Zoom In”** and **“Zoom Out”** icon to see the image close up or farther away.



itac IT ASSISTANCE CENTER

For further assistance:
ITAC Call Center: 512-245-ITAC (4822)
Live Chat: <https://livechat.tr.txstate.edu>


A Classroom Technology Tool for Remote Learning!

Use the ELMO MX-P2 as a *web cam*, *microphone*, and as an *alternative* to writing on the whiteboard. Easily integrates with **Zoom**.

Flip to the other side of this user guide to see an explanation of these controls!



Collapsed Vs. Expanded



Adjustable Arm

Lift/Expand the collapsible arm & flip the camera head to adjust to you, the audience, or document.

Adjustable Camera Head

Rotate the camera head in various directions to optimize your camera experience. Use this **4k camera** to give the audience a view of yourself during a lecture or in place of the classroom whiteboard as you instruct.

Tilt

Twist


Turn



Getting Started with Zoom

Steps for First Use

1 Start/Join a meeting in Zoom




2 Select the **up arrow** next to the **Start/Stop Video** icon and choose **"Video Settings."**

3 Set **Camera** to **MX-P2**.

4 Select **"Enable HD"** check box.

5 Deselect **"Mirror my video"** check box and close the **"Video Settings"** window.




6 Select the **up arrow** next to the **Mute/Unmute** icon to select the microphone for use.



PC: Select **"MX-P2"**



Mac: Select **"Capture Inactive"**



Tip: It is recommended to stand 2-5 ft. from the camera/microphone when speaking.

7 The MX-P2 is now ready for use. Use the **"Rotate"** button on the camera as needed to switch between webcam and doc cam use.

**Zoom settings are unique to your account on a specific computer. These steps should be performed the first time you use a room but should be retained thereafter.*